

2010 Version

Tork EWZ201 Programming Simplified

by Reliable Electric Products Co

- 1. Press MODE to advance to CLK. Press HOUR, MIN, to set current time. Press ENTER.
- 2. Press MONTH, DATE, YEAR to set current date. Press ENTER.
- **3.** Display will show "dSt on".
- *If Daylight Savings Time IS required, press ENTER and go to step 4.
- *If Daylight Savings Time <u>IS NOT</u> required, press **DEL** and screen will show "dst off". Press **ENTER** and go to step 4.
- 4. You should now see a screen with all dashes. Press MODE.
- 5. Press LATITUDE to advance to desired latitude. Display will show "LAtn". Press ENTER.
- **6.** Press **DAY**. All seven days will show on the display. Press **ENTER**.
- 7. Press MIN to advance to 15 minutes. Press EVENT. Display will show a minus "- " sign. Press ENTER.
- **8.** Press **DAY**. All seven days will show on the display. Press **ENTER** twice to return to selected latitude.
- 9. Press CH1/CH2 to switch to CH 2. Press ENTER.
- **10.** Press **DAY**. All seven days will show on the display. Press **ENTER**.
- 11. Press MIN to advance to 15 minutes. Press EVENT. Display will show a minus "- " sign. Press ENTER.
- 12. Press DAY. All seven days will show on the display. Press ENTER twice to return to selected latitude.
- **13.** Press *MODE* to return to AUTO.

You have now programmed your clock to function astronomically. This will allow your lights on both sides to turn on at sunset and turn off at sunrise. If you need to set specific off times or morning burns, go to Page 2.

Setting OFF schedules

- 1) From the AUTO screen, push **MODE** six times until you see a screen with all dashes.
- 2) Press the *HOUR* and *MIN* until you get the off time you want. If you want your lights to turn off at midnight, set the clock for 12:01 A.M. Make sure you have it set appropriately for PM or AM.
- 3) Press **CH1/CH2** to toggle between and select which channel you want assign that off schedule. Press **ENTER**.
- 4) If the other channel <u>DOES NOT</u> require an off schedule, go to step 7. If it <u>DOES</u>, go to step 5.
- 5) The screen should now show all dashes. Push *HOUR* and *MIN* until you get the off time you want. If you want your lights to turn off at midnight, set the clock for 12:01 A.M. Make sure you have it set appropriately for PM or AM.
- 6) Push *CH1/CH2* to toggle between and select which channel you want to assign that off schedule. Press *ENTER*.
- 7) If you <u>DO NOT</u> need to set the clock for a morning burn, press **MODE** two times and you will return to the AUTO screen. *You're finished programming!* If you <u>DO</u> require a morning burn, go to step 8.

Setting MORNING BURNS – NOTE: If you do not assign a morning burn schedule your lights will turn off at the times you entered in Steps 1 – 7 and remain off until sunset.

- 8) Your screen should now show all dashes. Push *HOUR* and *MIN* until the screen shows the time you want it to turn on in the morning. **Make sure you have it set to AM.**
- 9) Press **EVENT** and the screen should now read ON near the upper left-hand corner.
- 10) Push *CH1/CH2* to toggle between and select which channel you want to assign that on schedule. Press *ENTER*.
- 11) If the other channel <u>DOES NOT</u> require a morning burn, go to step 15. If it <u>DOES</u>, go to 12.
- 12) The screen should now show all dashes. Push *HOUR* and *MIN* until the screen shows the time you want it to turn on in the morning. **Make sure you have it set to AM.**
- 13) Press **EVENT** and the screen should now read ON near the upper left-hand corner.
- 14) Push *CH1/CH2* to toggle between and select which channel you want to assign that on schedule. Press *ENTER*.
- 15) Press **MODE** two times to return back to the AUTO screen. You're finished programming!

If the schedule you want to enter is not listed on this page or you're having trouble programming your clock, contact Reliable Electric Products at (866) 250-6445.

IF AT ANY TIME DURING THE PROGRAMMING PROCESS YOU WOULD LIKE TO START OVER FROM SCRATCH, PRESS MODE UNTIL YOU GET TO THE AUTO SCREEN. THEN PRESS ENTER, THEN EVENT, THEN ENTER AGAIN. THE CLOCK SHOULD RESET AND BLINK 12:00. NOW YOU CAN START OVER.